



CTP Reversible & Standard Fans

Reversible fans can be used to free the radiator of debris, keeping the engine cooler and running more efficiently. As a result, this prolongs the life of the engine.

How Reversible CTP Fans work



1. With the engine off, the ignition locked in the off position, and any required guarding removed, you are now ready to reverse your fan. There is a pink "DANGER" tag provided with your fan that should also be fastened to the ignition switch panel.



2. Individually reverse each blade by simply pushing inward (towards the hub) to compress the spring and then begin to rotate the blade; it should only turn in one direction.

3. Once the blade begins to rotate, you no longer need to keep pushing inward; continue to turn the blade toward the desired position.



4. Once the blade is rotated fully to the desired position, the blade will "spring" outward and lock itself into place. Now the blade will not be able to be turned around without pushing it inward again. The reversing of one blade is now complete; continue to reverse the remaining blades so that they are all in the same position.

5. Now that all of the blades have been reversed, the fan will force the air in the opposite direction. You are now ready to re-install the guarding, unlock the ignition switch, and continue operating the equipment with increased comfort.

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.

Part #	Description	Machine Model
1251362	REVERSIBLE FAN	D6R, D7H, D8N
1479672	REVERSIBLE FAN	D8K, 572R
1003607	STANDARD FAN	14H, 120H, 160H, 140H, 135H
1S0572	STANDARD FAN	D8, D8H
2040910	STANDARD FAN	320C, 330C
2459343	STANDARD FAN	320D, 320D L, 321D LCR
2P8907	STANDARD FAN	12G, 120G, 130G, 160G, 14G
2S4638	STANDARD FAN	637, 633C, 631C, D8H
3N2444	STANDARD FAN	255
4I7592	STANDARD FAN	320, 320L, 320N
4N2572	STANDARD FAN	330
4N3092	STANDARD FAN	C9, 350, 350L
4N3339	STANDARD FAN	3516, C15
4N8344	STANDARD FAN	955L, D5B, 943, 953, 936E
4N8871	STANDARD FAN	D4H
5I8000	STANDARD FAN	320, 320L, 320N, 315C, 315CL
5M5880	STANDARD FAN	D5, 950, 951, 955
5S1421	STANDARD FAN	966C, D7E
6I1363	STANDARD FAN	910, 931
6N0590	STANDARD FAN	D9G, D9N, 594
7E3557	STANDARD FAN	D7R
7N0476	STANDARD FAN	963B
7S0542	STANDARD FAN	951B, 950, D5, D4, 920, 930
7S0543	STANDARD FAN	D5
7S0546	STANDARD FAN	D6G2, D6D, D6E, 966C, 977L
8N0036	STANDARD FAN	235C, 235D, 627B
8N6584	STANDARD FAN	D6D
9M1904	STANDARD FAN	955K
9N6010	STANDARD FAN	322C, 325, 325L
9S9696	STANDARD FAN	D7G, D7F
1423391	STANDARD FAN	416C